


RUNNING-IN PERIOD						 HAFLINGER	Lubrication and maintenance jobs	NOTE ■ Reduce all intervals by half for pure cross-country use ▲ Check engine oil level at least after 300 km (200 miles)	NORMAL USE																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																	
Mixed road/cross-country use		Local authority and agricultural use		Tropical use					Mixed road/cross-country use		Local authority and agricultural use		Tropical use																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																													
Prior to use	Com-pulsory check	Prior to use	Com-pulsory check	Prior to use	Com-pulsory check				Daily (any type of use)	Reference on lubrication and maintenance diagram	Every	Every	Every	Every	Every	Every																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																										
	1 1250 km 750 miles 2500 km 1500 miles		2 100 km/60 mls 25 hours 200 km/120 mls 50 hours		1 625 km 375 miles 1875 km 1125 miles	2 100 km/60 mls 25 hours 200 km/120 mls 50 hours											1 1250 km 750 miles 2500 km 1500 miles	2 100 km/60 mls 25 hours 200 km/120 mls 50 hours	1 1250 km 750 miles 2500 km 1500 miles	2 100 km/60 mls 25 hours 200 km/120 mls 50 hours	1 1250 km 750 miles 2500 km 1500 miles	2 100 km/60 mls 25 hours 200 km/120 mls 50 hours																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																				

1) Such jobs can be done by yourself or by petrol station attendants (only if the engine is running). 2) In dusty conditions or tropical countries every 500 km/300 miles; for local authority use, every 40 km/10 hours. 3) Reduce time by half for stationary engines or dusty conditions. The filter insert must be marked "15" (filter grading) for tropical, local authority or stationary use. 4) For agricultural use or in dirty conditions clean cooling fins of cylinder, cylinder head and oil cooler every 2,500 km/1500 miles or 50 hours to prevent overheating of engine. Lubrication and maintenance of special-purpose attachments such as snow ploughs, winches, sprayers and so forth should be done in accordance with the manufacturer's instructions. Lubricants according to the lubrication chart.